

User Manual

Gen 2 Smart Controller (SKU: BB02-WC)





www.breezymed.com



Manufacturer and Contact Information

Manufacturer: Breezy Med

Address: 317 Commercial St NE, Suite 102 Albuquerque, NM 87102

For product information, sales, service, and technical support:

https://breezymed.com/ Customer Support Phone: (833) 273-3991 Email: info@breezymed.com

This manual covers the model: Gen 2 Smart Controller (BB02-WC)

SPECIFICATIONS:

Dimensions: 176.8 × 84.9 × 15 mm (6.96 x 3.34 x 0.59 inches)

Weight: 324 g (0.717 pounds)

USB: Type C

Wi-Fi: WLAN 802.11 a/b/g/n/ac 2.4GHz/5GHz

Bluetooth: Bluetooth 5.2

Splash, Water & Dust Resistant



Environmental Considerations

This section provides information about the environmental impact of the product.

Product End-of-Life Handling

Observe the following guidelines when recycling an instrument or component:

Equipment recycling. Production of this device required the extraction and use of natural resources. The device may contain substances that could be harmful to the environment or human health if improperly handled at the product's end of life. To avoid the release of such substances into the environment and to reduce the use of natural resources, we encourage you to recycle this product in an appropriate system that will ensure that most of the materials are reused or recycled appropriately. It is recommended that this device be taken to a certified Waste Electronic and Electrical Equipment recycler.



Do not throw in trash at end of product life.



Contents

Manufacturer and Contact Information
Environmental Considerations
BB02-WC Breezy Smart Controller Setup
Controller navigation overview5
Powering on controller6
General Controller Configuration6
Log-in7
Devices Screen Overview
Menu Page Overview
Adding a Favorite
Device Control Page15
Fog Time
Button Mode Slider
Schedule Button
Edit Device Name Button
Remote Controlled Operation21
Device Status Icons
Breezy Link
Breezy Spot



BB02-WC Breezy Smart Controller Setup

It is recommended that you charge the controller fully before use.

Controller navigation overview

Basic controls are the same as an Android phone.



Overview of Breezy Smart Controller device.

- 1. Power Key press *power key* & *Volume* + to restart controller
- 2. USB Connector Plug in cable and power supply to charge device.
- 3. Gesture Navigation Bar Used to navigate to home screen.
- 4. Volume -
- 5. Volume +








Powering on controller

 Power on the controller by pressing and holding the power key for 5 seconds until the controller vibrates and the screen turns on.

General Controller Configuration



- 1. The controller will auto-launch to the login screen. Swipe up from the bottom of the screen to display the Breezy Kiosk screen.
- 2. To Configure the general settings on the controller (Wifi, Bluetooth, etc), press the gear logo on the Kisok screen
- 3. Press Configure Wifi to connect to a Wifi network only necessary if cellular connectivity is poor.
- Press Reset Bluetooth to stop and restart the Bluetooth services

 only necessary if the controller can't connect to a Breezy device
- 5. Press Return to Home to return to the main Breezy Kiosk screen. The login screen will auto launch after 10 seconds.




Breezy Smart Controller App

Log-in

10:12 🛢 📓 🔹 🔹 🕯 🖓 🕮	11:24 🖻 🖻 🔰 🐐 📲 🗺 👉	11:37 🛢 🗟 🔹 🕸 🖓il R 🕸 🖘
	< Create Account	< Confirm Account
Breezy Smart Controller		
🖿 Email	🖬 Email	
Password O	B Password 💿	Security Code
Forgot Password?		Resend Code
Sign In	Confirm Password	Confirm Account
Don't Have An Account? <u>Sign Up</u> Powered by Breezy Med 2	Create Account	
		Verification code sent by OK EMAIL to r***@b***.

- 1. Tap the Breezy Smart Controller button on the Breezy Kiosk screen if the log-in page doesn't auto launch
- 2. Sign up for a new Breezy Med account or Sign In to an existing account. If *Sign Up* is selected, an email and a password will be required. One-time email verification will be required for the first sign in.





- 3. If an account already exists and the password needs to be reset, click enter user's email and tap Forgot Password?
- 4. A new password can be entered. A Security code will be sent to the user's email and will be required to reset the password



Sites : Sites : Sites	11:38 🛢 📓 🔹 🕸 🔐 R 🕅 🚳	🚥 11:38 🖻 🖬 🕸 米染l R	R 11:39 🖹 🗟	\$ 这 .ul R 9000	11:40 🖻 🖥	≱炎I ^R %団>
	Sites	: Sites	: Sites	:	Sites	:
Create Site Create Site Cr	Create Site	The site created can be used to monitor and manage Breezy Devices. The site name is commonly a company name The site name can be modified and other users can be invited from the Breezy Cloud dashboard in your internet browser of choice.	e ed ed	Continue	Smart Controller Controller (Optional) This controller wil as a trusted devi site. This controller allowed to upload site data until a u on the controller.	S/N: 000401 Name I be added ce for the r will be d and retrieve ser logs out

- 5. Once a new account has been created, new users will be prompted to create a site for all local Breezy devices or join an existing site if invited from an existing site administrator. If creating a new site, the site is commonly named after the company or building where the devices will be located.
- 6. Once the site is created and selected from the available dropdown menu, the user must add the controller to the site. Optionally enter a name for the controller (example: 2nd floor) then press continue.



Devices Screen Overview



- Once a user has logged in, the controller will display the Breezy Blue Scanning screen. Press the < icon to navigate to the Devices screen.
- 2. Press the breezy blue, breezy link, or breezy spot buttons to configure and control the respective devices.



Breezy Blue



Devices are shown under Site Devices or Other Devices. When a device has been connected to, it is moved to Site Devices. One device can also be added as a Favorite Device by pressing the + Add Favorite Device button. The favorite device will always be shown at the top of the screen. Devices can be removed from the Site devices list on the Breezy Cloud dashboard located at <u>Cloud.breezymed.com</u>

- Menu button Site and app information is available here. Bluetooth Connections can be refreshed by pressing the Repair Connections button.
- 2. Identify Used to identify the device. Pressing this button will flash the Breezy Blue ring light Blue/Yellow for 5 seconds to Identify the device.
- 3. Breezy Blue status The current device status and tank level.



www.breezymed.com




Menu Page Overview



- Repair Connections button Button stops, then restarts Bluetooth scan. This is useful if the scanning list is not updating properly.
- 2. Clear Favorite Device button Button clears device from the Favorite Device on the scanning screen.
- 3. Site information The site the controller is currently associated with.
- 4. Logout button Button logs user off the controller and removes the controller from the site.
- 5. App Version The version of the currently installed app.



Connecting to a device



- 1. All the available devices are shown as a list on the scanning screen.
- 2. Select a device to connect to. For example, "001181".
- 3. If the device hasn't been connected to previously, leave Allow access to your contact and call history unchecked and press *Pair* in the pop-up window.
- 4. Once paired, the device control page will load.



Adding a Favorite

12:27 🖥 創 🕴 👘 🖄 .ul R 晉(100)	12:27 🖥 🖻 🔋 🔌 🔐 R 등 🖽 B	12:27 🖥 🔋 🔹 👌 👔	12:54 🖻 🖹 👔 👔 👔 👔 🕅 🕅 🕅 🕅
< Scanning :	< Scanning :	< Scanning :	× I
——— Favorite Device ———	——— Favorite Device ———	——— Favorite Device ———	Consult o
+ Add Favorite Device	+ Add Favorite Device	001181 🗸 🧧 🔍	Scanning Repair
Site Devices	Site Devices	Site Devices	Connections
001181 🗸 📕 🔍	001181 🗸 🗧 🔍	Other Devices	Clear Favorite Device
Other Devices		001012 🗡 🔳 🔍	Trusted Controller
001012	Select Favorite Device	001222	Site test site Q
001222	001181		[→ Logout
	Cancel Continue		App Version 2.2.0-android

- 1. Once Connected to, the device will be shown as a site device on the scanning screen
- 2. On the scanning screen, press the + Add Favorite Device button
- 3. Select favorite device from drop down list
- 4. Favorite device will now show at the top of the screen.
- 5. A new favorite can be selected by pressing the menu icon on the scanning screen, then pressing the Clear Favorite Device button. A new favorite device can then be selected on the scanning screen



Device Control Page




- Device Name The default name is configured as the Breezy Blue's serial number shown on the bottom label of the device. This can be renamed.
- Device Menu Button Opens the device menu with the options to view device and account information, edit or create a fogging schedule, rename the device, or change the Button mode setting.
- 3. Tank level Shown in six increments (empty, 20%, 40%, 60%, 80%, and full). A red tank indicator is displayed when nearly empty. See the Breezy Blue User Manual for instructions on refiling the tank with Breezy Med approved solution.
- 4. Breezy Controller status Icon This is associated with the status of the device. See the explanation of icons in Table 1.
- 5. Start Fog Buttons Used to initiate a fogging event. Each Start Fog Button can be customized for name and fog duration.
- 6. Current Fog Time Displays fog duration that will be used for push button or scheduled modes.



Fog Time

Fog Time defines the amount of time Breezy Blue dispenses fog in the area.



- 1. Fog Time is set to 30 seconds at the factory. It is updated each time a fog event is started from one of the 4 buttons to the time defined by the button. Note that when Breezy Blue is in the disabled state, the buttons are named Set xx Sec Fog Time instead of Start xx Sec Fog Time. Current Fog time is used by the push button and schedule modes and is shown next to the tank level icon.
- 2. A fogging time of up to 30 minutes can be configured by holding one of the 4 buttons on the device control screen until the controller vibrates then using the number scroll to select minutes and seconds. The button can optionally be named by entering text in the *Custom Label* field, then press *Continue*.
- 3. If the device is disabled, the new fog time is updated immediately in the Current Fog Time. If the device is in any other state, the Current Fog Time will be updated when a fog event has been started using that button.







Button Mode Slider

Enable the Button mode slider to allow Breezy Blue operation without a remote. Disable this slider for remote control and scheduled operation only – recommended for devices left in public areas. The Breezy Blue is factory configured with Button mode enabled – Breezy Blue begins fogging cycle when button is depressed.






D001189 Rev A.0

www.breezymed.com

Schedule Button

<u>SCHEDULE</u> Allows the operator to define a schedule for Breezy Blue to automatically fog up to ten repetitive occurrences.



- 1. Press the *Edit Device Schedule* button on the device after selecting the menu button.
- 2. Press the "+" button to add schedule.
- 3. Select the desired time of the day and press CONTINUE.
- 4. Select the days of the week the schedule should fog. All days of the week are selected by default.
- 5. Repeat steps 1 to 4 to schedule additional times for the Breezy Blue to fog.



<u>DELETE SCHEDULE</u> Allows the operator to clear the existing schedule so Breezy Blue will no longer fog on a regular schedule.


12:27 🖥 🐧 🔹 🕸 🔐 🕅 🕅 🕅	09:59 🛢 🗟 🔹 🖇 议.al	R % TEO	09:57 🖹 🗟	参 12 . al R 191000	09:58 🖻 🗟	考 设il R 190000
< 001181 Device Control	×	:	< 001181 Schedule	:	< 001181 Schedule	:
Current @ Fog Time: 1 Min	Device Name breezy test Serial 001181 MAC 84:71:27:24:F7:09 Firmware 26	9 2:	Controller Time Device Time Device	06/04/2025 09:57:32 AM 06/04/2025 09:57:59 AM NoDST	Device	06/04/2025 09:58:32 AM 06/04/2025 09:58:59 AM NoDST
Start 15 Sec Fog (Hold to Customize)	Button Mode Edit Device Schedule No schedules set		Time Zone 10:00 PM Everyday		Time Zone	NODOT
Start 30 Sec Fog (Hold to Customize)	Edit Device Name Trusted Controller Site test site ID a53d6/aacc					
Start 1 Min Fog (Hold to Customize)	E+ Logout App Version 2.2.0-android					
Start 2 Min Fog (Hold to Customize)			e			+
					_	

- 1. On the menu page, press the Edit Device Schedule button
- 2. On the Schedule screen, press the delete icon.
- 3. The schedule will be deleted.



Edit Device Name Button

Limited to 24 characters. (ex. Class 202, Firehouse 12, Casino 1st floor)



- 1. Press the menu button and press the *Edit Device Name* button to edit the name.
- 2. Type a new name in the text field.
- 3. Press the Continue button.
- 4. The new name will be shown as the device name the new name will persist even when the device is not connected to the controller.



Remote Controlled Operation

12:00 S B C 001181 Device Control	¥Ջ"dR☆@) 11:53 : 〈	a G 001181 Device Control	\$K, R??™ 1	1:53 B Device Control	¥ Q ad R Store	11:57 CO1181 Device Control	\$ 10(R ۲۰۰۰). •	11:53 B G CO01181 Device Control	≱ 股I R ∰rm.
	yrrent ? 7 Time: Sec		urrent 🥝 g Time: 🍦 5 Sec		Current 🥥 Fog Time: 5 Sec		Current 🥝 Fog Time: 5 Sec	<u></u>	Current @ Fog Time: 5 Sec
Start 5 Sec Fo (Hold to Customiz	g .e)	j 5 Sec	(🖲 1 Sec				Ū 9 Min	58 Sec
Start 30 Sec Fo (Hold to Customiz	pg (e)					Sto	q		
Start 1 Min Fo (Hold to Customiz		Stop Foggin	g	Sto Fogg		Fogg	jİng	Skip Se Tim	
Start 2 Min Fo (Hold to Customiz									
					_		_		_

- 1. Press the desired fog time button of the four "Start xx Sec Fog" buttons.
- 2. A countdown of 7 seconds to fogging will initiate. The Breezy Blue waistband light will flash red, and there will be an audible warning to leave the area. Press the *Stop Fogging* button on the controller or the push button on the Breezy Blue to cancel the fogging event.
- 3. When the countdown ends, fogging will begin. The Breezy Blue waistband will turn solid red. Press the *Stop Fogging* button on the controller or the push button on the Breezy Blue to cancel the fogging event.
- 4. After fogging, the Breezy Blue device will enter a 10-minute fog settling time indicated by a flashing yellow light on the waistband. Press *Skip Settling Timer* to return Breezy Blue to ready to fog state if necessary.
- 5. When settling has completed, the Breezy Blue waistband will return to a blue color, and the controller will display the four fog time buttons. At this time, the area can be opened for ventilation, and the HVAC system can be turned on to prepare the area for re-entry.





Viewing Fogging Logs

The Fogging logs from all the Breezy Blue devices at the site can be viewed at <u>Cloud.breezymed.com</u>

Note: Fogging logs are only available up to the time of the last instance the controller opened the Device control screen for each Breezy Blue Device.



D001189 Rev A.0

Device Status Icons

Table 1: Device status icons

Status	LED Ring	Button LEDs	Audio	Status Icon	Breezy Controller Icon
Not currently seen by controller, but previously seen by controller	Any option below	Any Option below			?
Idle + Enabled	Blue	Off		Ready to Fog	
Idle + Disabled	Yellow	Yellow		Disabled	X
Fogging Countdown	Red, blinking	Red, blinking	[Beep] "Alert, disinfectant fogging will begin soon. Please leave the area or press the disable button."	Countdown	
Fogging	Red	Red		Fogging	
Fog Settling	Yellow, blinking	Off		Settling	
Firmware updating	White, then magenta	Off		Progress bar	
Error	Magenta, blinking	Off		Error	



Breezy Link

Breezy Link Assistant offers Wi-Fi configuration for Breezy Link devices using a Bluetooth connection from the Smart Controller.


12:26 📴 💈	\$ 段I ^R ≌ 1000	12:52 🗟 🏮	\$ 读 .ul ^R ≌Ⅲ	12:54 🧕 🔋	\$ 段I ^R ≌Ⅲ	12:55 🖥 🔒	\$以I ^R ≌0000
Devices	:	< Scanning	:	< Link 001001 Device Control	:	< Link 001001 Device Control	:
		Site De	vices ———				
		Other D	evices ———		_		_
o bree	zy	Breezy Link 001002	⊥≈●	Ethernet Connected	- Å	Ethernet Connected	
		Breezy Link 0010	101 占 🔆 🌰			Configure	Wifi
		Breezy Link 0010	116 📩 🔆 🌰			중 BWR_GUES	т
1	Wifi		Network Pas	word 💿 📘			
S bree	zy	Breezy Link 0010		Disconnected		Link Security	Code
IUK I							
						<u>Cancel</u> <u>C</u>	ontinue
				Cloud Connecte	d 🕒	Cloud Connect	ed 🧥
bree	70						
Spot	-9						
				Configure V	Wifi	Configure	Wifi
			_		-		_

- 1. Tap the Breezy Link button on the devices screen.
- 2. A list of Breezy Link devices that can be configured will be displayed. Selecting one of the Link devices will open a notification requesting to pair to the device.
- 3. Once paired to the Breezy Link device a control page will be available. This page allows for Wi-Fi configuration of the Breezy Link to a network or disconnecting from the current Wi-Fi network.
- 4. When connecting to a Wi-Fi network, the network password and the security code printed on the Breezy Link label will need to be entered into the appropriate text fields.



Breezy Spot

Breezy Spot Assistant allows Breezy Spot devices to be added to the site and configured.



- 1. Tap the Breezy Spot button on the devices screen.
- 2. When the controller is stationary, the list will be populated with Breezy Spot device within Bluetooth range. If the controller is in contact with a Breezy Spot, that Breezy Spot will report a strong RSSI value (generally -30 to -55).
- 3. Tap the Setup New Breezy Spot button.
- 4. Using the camera on the rear of the controller, move the QR code on the bottom of the Breezy Spot into the image shown on the screen. When the QR code has been read, the camera will close. Move the controller closer and further from the QR code if you have issues reading the QR code.
- 5. Enter a name for the location (example: Floor 2 room 100) and press continue.
- 6. The Breezy Spot device will be shown in the Site devices and named with the location name,
- 7. Location names and Breezy spots associated with a location can be updated at <u>Cloud.breezymed.com</u>



Troubleshooting

PROBLEM	POSSIBLE CAUSES	SOLUTION
Controller will not properly control a Breezy Blue device	Bluetooth pairing is not valid	Press Repair Connections button from menu on scanning screen
Controller shows "?" next to each Breezy Blue on list, or will not connect to a Breezy device	Controller display is not properly refreshing	Press the Repair Connections button in the breezy blue menu, or press the Reset Bluetooth button in the Kiosk settings screen
The controller will not update the kiosk or Breezy app to a newer version	Poor data connection or Kiosk has become unresponsive	Move to a location with a good data connection, or press the <i>Restart Kiosk</i> in the Kiosk setting screen



D001189 Rev A.0

www.breezymed.com

Pag<u>e 26</u>

LIMITED WARRANTY (USA/CANADA)

Breezy Med warrants that this product will be free from defects in materials and workmanship for a period of one (1) year from the date of shipment. If any such product proves defective during this warranty period, Breezy Med, at its option, either will repair the defective product without charge for parts and labor, or will provide a replacement in exchange for the defective product. Parts, modules and replacement products used by Breezy Med for warranty work may be new or reconditioned to like new performance. All replaced parts, modules and products become the property of Breezy Med.

In order to obtain service under this warranty, Customer must notify Breezy Med of the defect before the expiration of the warranty period and make suitable arrangements for the performance of service. Customer shall be responsible for packaging and shipping the defective product to the service center designated by Breezy Med, with shipping charges prepaid. Breezy Med shall pay for the return of the product to Customer if the shipment is to a location within the country in which the Breezy Med service center is located. Customer shall be responsible for paying all shipping charges, duties, taxes, and any other charges for products returned to any other locations.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. Breezy Med shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than Breezy Med representatives to install, repair or service the product; b) to repair damage resulting from improper use or connection to incompatible equipment; c) to repair any damage or malfunction caused by the use of non-Breezy Med supplies; or d) to service a product that has been modified or integrated with other products.

THIS WARRANTY IS GIVEN BY BREEZY MED WITH RESPECT TO THE PRODUCT IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED. BREEZY MED AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. BREEZY MED' RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. BREEZY MED AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER BREEZY MED OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.



www.breezymed.com