

Scheduled Mode

STEP-BY-STEP GUIDE - BREEZY BLUE® DISINFECTION



1. Place Breezy Blue

Position Breezy Blue in a corner on a flat surface, preferably elevated off the floor, with the jets pointed towards the center of the room.



2. Schedule in the App

Using the Smart Controller, schedule days/times when the room will be unoccupied for at least two hours. Close the door and place the door-handle warning sign prior to the scheduled time.



3. Fog Autonomously

Breezy Blue will autonomously fog at the scheduled time. The fog needs at least 10 minutes of contact time with the door closed. For quick re-entry, open the door to ventilate the room.



4. Refill as Needed

Regularly check the Smart Controller or Breezy Cloud™ to ensure that your Breezy Blues have enough disinfectant to continue operating.



For more guidance, visit
BreezyMed.com/Support
or scan the QR code.

